

INSTALLATION INSTRUCTIONS | PART NO. 106-0650

BILL OF MATERIALS:

STEP 1: (Carefully read all instructions before installation) Disconnect the vehicle's battery before removal of the OEM exhaust system. This will prevent electrical accidents and will reset the computer if it applies to the vehicle. Remove existing exhaust system from the vehicle. Only remove parts that will be replaced. Clean existing flange with a wire brush to ensure proper sealing.

STEP 2: Attach the **Inlet Assembly** to the existing exhaust and isolator with the supplied hardware and gasket.

STEP 3: Attach the **Muffler Assembly** to the **Inlet Assembly** and existing Isolator with supplied Clamp.

STEP 5: Attach **Tailpipe Assembly** to **Muffler Assembly** and existing isolators with supplied Clamp.

STEP 6: Ensure new exhaust is not contacting any portion of the underbody of the vehicle or drivetrain.

STEP 7: Tighten all clamps starting from rear of the vehicle. **(DO NOT EXCEED 30FT-LB WHEN**

WARNING:

When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.



BRExhaust recommends professional installation for all products

Technical Support: 1-800-631-7271

BRExhaust — 1901 Corporate Ctr, Oceanside, CA 92056