

2002-2006 FORD ESCAPE 3.0L REAR MANIFOLD



"Y" PIPE



DIAGRAM 1

Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

Step 1:(Carefully read all instructions before installation) To remove the OEM rear manifold converter, first you must remove the "Y" pipe assembly. (See diagram 1) Next you must remove both the EGR and O2 sensor from the converter assembly. (See diagram 2) Next you must unbolt the alternator. Do this by first removing the plastic covering on the passenger side. (See diagram 3) Next loosen the belt tensioner bolt. (See diagram 4) Now remove the alternator bolts and remove the alternator. (See diagram 5) Once the alternator has been removed, you're now ready to remove the manifold bolts and carefully remove the converter.

*MAGNAFLOW Performance Exhaust recommends professional installation on all their products

Technical support: 1-800-959-9226 ext. 4500

MAGNAFLOW Performance Exhaust - 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688

2002-2006 FORD ESCAPE 3.0L REAR MANIFOLD



Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

DIAGRAM 2



DIAGRAM 3

*MAGNAFLOW Performance Exhaust recommends professional installation on all their products

Technical support: 1-800-959-9226 ext. 4500

MAGNAFLOW Performance Exhaust - 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688

2002-2006 FORD ESCAPE 3.0L REAR MANIFOLD



DIAGRAM 4

Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.



DIAGRAM 5

*MAGNAFLOW Performance Exhaust recommends professional installation on all their products

Technical support: 1-800-959-9226 ext. 4500

MAGNAFLOW Performance Exhaust - 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688